


Infrared sensor for 4MH400WU06

Clock (4MH400WU06)




How to set the infrared sensor unit

1. Connect the infrared sensor unit.
Plug the 2 connectors from clock into the connection port of the sensor unit.
2. Remove the release paper of the two-sided tape on the sensor unit.
3. Tape the sensor unit behind the lower part of the wooden frame.
Apply and press the two-sided tape to the sensor for three (3) seconds to secure properly.
4. Make the connector cables tied and fix with some tapes on the back case.
5. Insert the remaining cable into the hole of clock.



Black > Red > Blue > Yellow

* Different from the indication on the circuit board




Melody ON/OFF switch

How to use the motion sensor for demonstration

1. Make sure the Melody ON/OFF switch is "ON".
2. Set the ON/OFF switch of the sensor unit "ON".
3. The effective distance is around 78 inch (2m), the angle is 120 degree.

*While playing the melody, the Infrared sensor does not work.



Battery life

Infrared sensor OFF ; Around 1 year (same as normal clock)

Infrared sensor ON ; Around 1 month (48 times / day)