

## Chronometer 4MH442WU08



4MH442WU08	
Name	Chronometer
Movement	Magic Motion – Gadget
Case	ABS
Number of Melodies	30
Swarovski Crystal	Yes
Night Shutoff	Yes
Volume Control	Yes
On/OFF Switch	Yes
LED Lights	Yes
Low Battery LED	No
Batteries	2xD
Case Pack	4
UPC Code	0-09136-44208-1

We give you the Chronometer. Reminds you of some of the great watches and clocks of the past. On the hour, the gears take a move, meanwhile, the dial takes a full revolution around while playing one of 30 melodies. It reads the temperature, moisture has motion, and it tells time. Designed beautifully with a continuous rotating gear at the bottom and 6 Swarovski Crystals. The clock is battery quartz operated.



Dimensions



Back



Buttons



Features



Lifestyle



## Chronometer

4MH442WU08

Melody	Group	Order
Thais' Meditation	1	1
Air	1	2
Greensleeves	1	3
Ave Maria	1	4
Traumerei	1	5
Beautiful Dreamer	1	6
Jesu, Joy Of Man's Desiring	1	7
Nocturne op. 9-2	1	8
What A Friend We Have In Jesus	1	9
Liebestraum No. 3	1	10
Morning Mood - Peer Gynt	1	11
Amazing Grace	1	12
Tale From The Vienna Woods	2	1
Four Seasons - Spring	2	2
Sonata fur Klavier K. 545-1	2	3
Aura Lee	2	4
Valse "Coppelia"	2	5
Canon	2	6
Voice Of Spring	2	7
In The Garden	2	8
Danza Dell'ore	2	9
Invitation To The Dance	2	10
Four Seasons - Winter	2	11
My Country, 'Tis of Thee	2	12
The First Noel	3	1
Jingle Bells	3	2
Silent Night	3	3
Deck The Halls	3	4
Joy To The World	3	5
We Wish You A Merry Christmas	3	6

**Rhythm USA, Inc.**

8601 Dunwoody Place, Suite 150  
Atlanta, GA 30350

Tel: 770-640-6311 Fax: 770-640-6312